

## How to – Calibrate the Bottom Sensors (touch)



Flip the red switch on the device's backside „ON“ („I“).

Press within **two seconds** the buttons „M“ and „start/stop“ and hold at the same time.



When the display starts to flicker, just release and press briefly the „on/off“ button.

You will hear a noise and the display shows:



Tap 11 times in succession „M“.  
All display lights will blink.

After that, press 4 times on „M“ again.





The display shows this.

Please put the device on the ground, provided for the calibration.

Press „start/stop“ for starting the calibration

Following displayed:

**Daily, Hour, Turbo**



Displayed after successful calibration.



Flip the red power switch „OFF“ and „ON“.

Test the device on the provided surface.

Please pay attention, that the calibration on dark surfaces can cause errors in the recognition of abysses. It can cause crashes. Please put some obstacles in front of the abysses.

If there should be more problems, please contact: [support@moneual.es](mailto:support@moneual.es)